



PN/MQTT Coupler Manual

Version 2 | 6/18/2021 | for firmware V1.04 and above



Link to newest version of
manual

Notes

All rights reserved, including those related to the translation, reprinting, and reproduction of this manual or of parts thereof.

No part of this manual may be reproduced, processed, duplicated, or distributed in any form (photocopy, microfilm, or any other methods), even for training purposes or with the use of electronic systems, without written approval from Helmholtz GmbH & Co. KG.

All rights reserved in the event of the granting of a patent or the registration of a utility model.

To download the latest version of this manual, please visit our website at www.helmholtz.de.

We welcome all ideas and suggestions.

Copyright © 2021 by

Helmholtz GmbH & Co. KG

Hannberger Weg 2 | 91091 Großenseebach

All trademarks shown or mentioned in this document are the property of their respective owners or manufacturers. The representation and naming serve exclusively to explain the use and setting options of the products documented here.

Revision Record:

Version	Date	Change
1		First version
2	6/18/2021	Update for firmware V1.04 Microsoft Azure example added

Contents

1	General	6
1.1	Structure of the manual	6
1.2	Target audience for this manual	6
1.3	Safety instructions	6
1.4	Note symbols and signal words	7
1.5	Intended use	8
1.6	Improper use	8
1.7	Liability	9
1.7.1	Disclaimer of liability	9
1.7.2	Warranty	9
1.8	Open Source	9
2	Security recommendations	10
3	System overview	11
3.1	General/area of application	11
3.2	PN/MQTT Coupler Features	12
4	Installation and removal	13
4.1	Access restriction	13
4.2	Mounting and minimum distances	13
4.3	Electrical installation	13
4.4	Protection against electrostatic discharges	13
4.5	EMC protection	14
4.6	Operation	14
4.7	Recycling / WEEE	14
5	Connection	15
5.1	Power supply	15
5.2	Network	15
5.3	network connector	16
6	Install GSDML file	17
7	Configuration in TIA Portal	18
7.1	Parameterization of the PN/MQTT coupler	18
7.2	Operating principle of the PN/MQTT coupler	20
7.3	Assign a name to the PN/MQTT coupler	22
8	Configuration of MQTT connection	23

8.1	Access to the web page	23
8.2	MQTT basic configuration	24
8.3	MQTT Payload formats	26
9	Status and control via the PLC	27
9.1	Status of PN/MQTT Coupler	27
9.2	Control of PN/MQTT Coupler	27
9.3	Subscribe Module.....	27
10	MQTT encryption and authentication.....	28
10.1	Generator for certificates and SAS tokens	30
11	More MQTT settings	31
11.1	Topic Mode	31
11.2	Last Will Message.....	32
11.3	„Communication Enable“ and „Communication Stopped“ messages	33
12	Further functions in the web interface.....	34
12.1	Module status.....	34
12.2	Export/Import of the configuration	34
12.3	Account.....	35
12.4	Upload TLS certificates for HTTPS.....	35
12.5	SNTP Settings	35
12.6	Firmware update	36
12.7	Reset to factory settings	37
12.7.1	Reset to factory settings via website	37
12.7.2	Reset to factory settings via "IPSet" tool	37
13	Diagnosis via LEDs	38
14	Client tools for MQTT data exchange.....	39
14.1	MQTT Explorer	39
14.2	MQTT.fx V5	39
14.3	MQTT Box	39
15	Application example „mosquitto“	40
15.1	Mosquitto Test-Host	40
15.2	Install and use Mosquitto locally.....	40
16	Application example „HiveMQ“	41
16.1	Use of HiveMQ in a virtual machine	41
16.2	HiveMQ Cloud.....	42

17	Application example „Amazon IoT Core“	44
17.1	Create a policy.....	45
17.2	Create „AWS IoT Things“	46
17.3	Configure PN/MQTT Coupler for AWS Access	49
17.4	Testing the MQTT Connection in AWS.....	50
18	Application example „Microsoft Azure“	52
18.1	Create device in Azure	52
18.2	Configure PN/MQTT Coupler for Azure	55
18.3	Checking the data transfer in Microsoft Azure	57
19	Technical data.....	58

1 General

This operating manual applies only to devices, assemblies, software, and services of Helmholtz GmbH & Co. KG.

1.1 Structure of the manual

This manual is divided into 19 sections.

[Section 1](#) contains general information and safety instructions.

[Section 2](#) refers to Security Recommendations.

[Section 3](#) explains the system overview and features of the product.

[Section 4+5](#) explain the mounting and electrical connection of the product.

[Sections 6-11](#) explain the configuration and programming of the product.

[Sections 12+13](#) describe functions for maintaining and diagnosing the product.

[Sections 14-18](#) contain application examples.

The technical data can be found in [section 19](#).

1.2 Target audience for this manual

This description is only intended for trained personnel qualified in control and automation engineering who are familiar with the applicable national standards. For installation, commissioning, and operation of the components, compliance with the instructions and explanations in this operating manual is essential.



Configuration, execution, and operating errors can interfere with the proper operation of the device and result in personal injury, as well as material or environmental damage. Only suitably qualified personnel may operate the devices!

Qualified personnel must ensure that the application and use of the products described meet all the safety requirements, including all relevant laws, regulations, provisions, and standards.

1.3 Safety instructions

The safety instructions must be observed in order to prevent harm to living creatures, material goods, and the environment. The safety notes indicate possible hazards and provide information about how hazardous situations can be prevented.

1.4 Note symbols and signal words



HAZARD

If the hazard warning is ignored, there is an imminent danger to life and health of people from electrical voltage.



WARNING

If the warning is ignored, there is a probable danger to life and health of people.



CAUTION

If the caution note is ignored, people can be injured or harmed.



ATTENTION

Draws attention to sources of error that can damage equipment or the environment.



NOTE

Gives an indication for better understanding or preventing errors.

1.5 Intended use

The "PN/MQTT Coupler" enables data exchange between a PROFINET network and MQTT brokers.

All components are supplied with a factory hardware and software configuration. The user must carry out the hardware and software configuration for the conditions of use. Modifications to hardware or software configurations which are beyond the documented options are not permitted and nullify the liability of Helmholz GmbH & Co. KG.



The device may not be used as the only means for preventing hazardous situations on machinery and systems.

Problem-free and safe operation of the device presumes proper transport, storage, setup, assembly, installation, commissioning, operation, and maintenance.

The ambient conditions provided in the technical specifications must be adhered to.

The device has a protection rating of IP20 and must be installed in an electrical operating room or a control box/cabinet in order to protect it against environmental influences. To prevent unauthorized access, the doors of control boxes/cabinets must be closed and possibly locked during operation.

1.6 Improper use



The consequences of improper use may include personal injuries of the user or third parties as well as property damage to the control system, the product, or the environment. Use the PN/MQTT Coupler only as intended!

1.7 Liability

The contents of this manual are subject to technical changes resulting from the continuous development of products of Helmholz GmbH & Co. KG. In the event that this manual contains technical or clerical errors, we reserve the right to make changes at any time without notice.

No claims for modification of delivered products can be asserted based on the information, illustrations, and descriptions in this documentation. Beyond the instructions contained in the operating manual, the applicable national and international standards and regulations must also be observed in any case.

1.7.1 Disclaimer of liability

Helmholz GmbH & Co. KG is not liable for damages if these were caused by use or application of products that was improper or not as intended.

Helmholz GmbH & Co. KG assumes no responsibility for any printing errors or other inaccuracies that may appear in the operating manual unless there are serious errors about which Helmholz GmbH & Co. KG was already demonstrably aware.

Beyond the instructions contained in the operating manual, the applicable national and international standards and regulations must also be observed in any case.

Helmholz GmbH & Co. KG is not liable for damage caused by software that is running on the user's equipment which compromises, damages, or infects additional equipment or processes through the remote maintenance connection and which triggers or permits unwanted data transfer.

1.7.2 Warranty

Report any defects to the manufacturer immediately after discovery of the defect.

The warranty is not valid in case of:

- Failure to observe these operating instructions
- Use of the device that is not as intended
- Improper work on and with the device
- Operating errors
- Unauthorized modifications to the device

The agreements met upon contract conclusion under "General Terms and Conditions of Helmholz GmbH & Co. KG" apply.

1.8 Open Source

Among other things, our products contain open source software. This software is subject to the relevant license terms. The relevant license terms, including a copy of the full license text, are downloadable from the product website. They are also provided in our download area of the respective products at www.helmholz.de.

Furthermore, we offer to send the complete corresponding source code of the respective open source software to you and to any third party as a DVD upon your request for a contribution towards expenses of Euro 10.00. This offer is valid for a period of three years. This offer is valid for a period of three years, calculated from the delivery of the product.

2 Security recommendations

Managed switches are network infrastructure components, and thus an important element in the security considerations of a system or network. When using the PN/MQTT Coupler, therefore please consider the following recommendations in order to prohibit unauthorized access to plants and systems.

General:

- Ensure at regular intervals that all relevant components fulfill these recommendations and possibly any other internal security guidelines.
- Evaluate your system holistically with a view to security. Use a cell protection concept with corresponding products.

You can find extensive information, for example, in the “ICS Security Compendium” of the Federal Office for Information Security (BSI):

https://www.bsi.bund.de/SharedDocs/Downloads/EN/BSI/ICS/ICS-Security_compendium.html



Physical access:

- Limit physical access to components of relevance to security to qualified personnel.

Security of the software:

- Always keep the firmware of all communications components up to date.
- Inform yourself regularly of firmware updates for the product. You can find information on firmware update in this manual.
- Only activate protocols and functions you really need

Passwords:

- Define rules for usage of the devices and the awarding of passwords.
- Update passwords and keys regularly
- Change standard passwords
- Only use strong passwords. Avoid weak passwords like, for example, “password1”, “123456789”, or similar.
- Ensure that all passwords are protected and inaccessible to unauthorized personnel.
- Do not use one password for various users and systems.

3 System overview

3.1 General/area of application

The MQTT protocol has become established in recent years as a simple transmission protocol for messages in the IoT world. MQTT stands for "Message Queue Telemetry Transport Protocol" and is an OASIS standard. Information on the MQTT protocol can be found here: mqtt.org



The MQTT protocol always uses a central broker for communication between devices, which receives messages from e.g. a sensor and forwards them to interested devices, e.g. a control unit.

When a sensor sends data to the broker, this is called "publish". If a device needs data, it must "subscribe" to the broker. The broker delivers the data to all subscribers when new data has arrived from the publisher.

Data is always transmitted under a freely definable identifier - the "Topic". The "Topic" is a descriptive text, e.g. "Temperature". In order to distinguish between different topics of the same type, groupings are used, e.g. "Living room/temperature". The groupings are divided by a slash ('/'). Thus the data can be mapped into more complex structures: "Upper floor/Living room/Temperature" or "Upper floor/Living room/Humidity".

The data delivered via MQTT can be transmitted in binary format, text format or structured in JSON format.

With the PN/MQTT Coupler a transfer of values between a PROFINET controller (PLC) and a MQTT broker is possible. It is possible to send values from the PLC via PROFINET to a broker ("Publish") as well as to subscribe values from a MQTT broker and receive them in the PLC via PROFINET ("Subscribe").



The integration into the PLC engineering tool is enabled by a GSDML file, an additional extra configuration software is not necessary. The configuration of the I/O data to be exchanged is done in the Siemens engineering tool. All settings for the MQTT connection can be done on the web page of the device.

MQTT brokers can be connected both locally ("On premise") and via the Internet ("Cloud"). A local broker can be operated, for example, with the open-source software "Mosquitto" in the company network on a PC/server or also on a small computer, such as a Raspberry PI.



NOTE The PN/MQTT coupler can only establish a connection with one broker! If the data is also to be distributed to other brokers, the connection must be established between the brokers (Multi Broker).

In the cloud, IoT systems such as HiveMQ, Amazon IoT, Microsoft Azure or Siemens Mind-sphere (*in preparation*) can be connected directly. For a description of how to connect to the various cloud systems, see later in this manual or ask support.

3.2 PN/MQTT Coupler Features

The "PN/MQTT Coupler" has the following features:

- PROFINET IO Device as of IEC 61158-6-10
- Up to 1024 bytes of input and output data
- Supports OASIS MQTT standards V3.1.1 and V5
- Easy assignment of IO data via GSDML file
- Up to 100 values can be configured for transmission at the same time (100 slots)
- Flexible configuration via web browser
- Separate networks for PROFINET and MQTT connection
- Connection to brokers in the local network or directly with the "cloud"
- Authentication (password, certificate) and encryption (TLS)
- Supports AWS IoT, Microsoft Azure, HiveMQ, IBM Watson, Google IoT, Siemens Mindsphere (*in preparation*)
- Very compact design for DIN rail mounting
- Redundant power supply
- Galvanic isolation of the networks



4 Installation and removal

4.1 Access restriction

The modules are open operating equipment and must only be installed in electrical equipment rooms, cabinets, or housings.

Access to the electrical equipment rooms, cabinets, or housings must only be possible using a tool or key, and access should only be granted to trained or authorized personnel.

4.2 Mounting and minimum distances

The PN/MQTT Coupler can be mounted on a DIN rail and installed in any position. It is recommended to keep minimum distances when mounting. By keeping the minimum distances

- the modules can be mounted or dismantled without having to dismantle other parts of the system.
- there is enough space to connect all existing connections and contacting possibilities with commercially available accessories.
- There is space for any necessary cable routing.



ATTENTION

Installation must be carried out in accordance with VDE 0100/IEC 364 and applicable national standards. The device has protection level IP20. If a higher degree of protection is required, it must be installed in an enclosure or a control cabinet.

4.3 Electrical installation

Observe the regional safety regulations.

4.4 Protection against electrostatic discharges

To prevent damage through electrostatic discharges, the following safety measures are to be followed during assembly and service work:

- Never place components and modules directly on plastic items (such as polystyrene, PE film) or in their vicinity.
- Before starting work, touch the grounded housing to discharge static electricity.
- Only work with discharged tools.
- Do not touch components and assemblies on contacts.

4.5 EMC protection

To ensure electromagnetic compatibility (EMC) in your control cabinets in electrically harsh environments, the known rules of EMC-compliant configuration are to be observed in the design and construction.



ATTENTION

Observe all standards, regulations and rules regarding shielding when setting up the system and laying the necessary cables. Strictly adhere to the corresponding writings of the PROFIBUS user organization for setting up PROFINET.

Errors in the shielding can lead to malfunctions or even failure of the system.

4.6 Operation

Operate the device only in flawless condition. The permissible operating conditions and performance limits must be adhered to.

Retrofits, changes, or modifications to the device are strictly forbidden.

The device is a piece of operating equipment intended for use in industrial plants. During operation, all covers on the unit and the installation must be closed in order to ensure protection against contact



ATTENTION

When the PN/MQTT Coupler is switched off, bus connections are interrupted! Before starting any work on the device, make sure that no impermissible interference occurs in connected systems when the bus connections are interrupted.

4.7 Recycling / WEEE

The company Helmholz GmbH & Co. KG is registered as a manufacturer with the HELMHOLZ brand and the device type "Small devices of information and telecommunications technology for exclusive use in households other than private households" as well as the following registration data:

Helmholz GmbH & Co. KG,
Location / Headquarters: 91091 Großenseebach,
Address: Hannberger Weg 2,
Name of authorized representative: Carsten Bokholt,
Registration number: **DE 44315750**



The electrical devices described in this document are to be recycled. According to Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), they must not be disposed of by municipal waste disposal companies.

5 Connection

5.1 Power supply

The PN/MQTT coupler must be supplied with DC 24 V at the wide-range input DC 18 ... 30 V via the supplied connector plug. The power supply is redundant, at least one supply path PS 1 or PS 2 must be connected.



NOTE

The housing of the PN/MQTT Coupler is not grounded. Please connect the functional earth terminal (FE) of the PN/MQTT Coupler properly to the reference gantry.

5.2 Network

The left RJ45 sockets "X1 P1" and "X1 P2" are used to connect the PROFINET network, the right RJ45 sockets "X2 P1" and "X2 P2" are used to connect the Ethernet network in which the MQTT broker is accessible. The ports X1 P1 and X1 P2, as well as X2 P1 and X2 P2 are each internally connected to a switch.

The interfaces X1 and X2 are logically separate networks and not physically connected. Thus a clear separation between the machine data (PROFINET) and the MQTT data connection is possible.

A network penetration with other functions by the PN/MQTT coupler is not possible.

The configured values are exchanged in the PN/MQTT coupler only as IO data between both network sides.

X1: PROFINET-Stack	Internal Memory	X2: MQTT Client
Outputs	→	Publish
Inputs	←	Subscribe



NOTE


If the MQTT broker needs to be placed in the same network (subnet) as the PROFINET PLC, the network X2 can be configured in the same subnet as the network X1. The interface X2 then needs its own IP address and must be connected to the network X1 with an Ethernet cable.

5.3 network connector


Pin	signal	RJ45 connector	color	Wire pair
1	TD+	Transmission Data +	Yellow	1
2	TD-	Transmission Data -	Orange	1
3	RD+	Receive Data +	White	2
4	-	-	-	-
5	-	-	-	-
6	RD-	Receive Data -	Blue	2
7	-	-	-	-
8	-	-	-	-

6 Install GSDML file

Please download the GSDML file ("GSDML-V2.35-Helmholz-PN-MQTT-coupler-____.xml") at www.helmholz.de or scan the QR code. Install the GSDML file in the "Tools" / "Manage device description file (GSD)" menu in the TIA Portal.




The PN/MQTT Coupler can be found in the hardware catalog at "Other field devices / PROFINET IO / Gateway / Helmholz GmbH & Co. KG".



7 Configuration in TIA Portal


Add the PN/MQTT coupler to the project and connect the coupler to the PROFINET network.



Name the device name and check the Ethernet address for the device.

7.1 Parameterization of the PN/MQTT coupler

The parameterization of the PN/MQTT coupler is performed via the PROFINET hardware configurator (e.g. TIA Portal). The PROFINET parameters and the I/O data to be transmitted via MQTT are defined here. The configuration of the MQTT network connection (connection to the MQTT broker) is set via the web page of the device.



MQTT IP-address mode (X2): Setting the IP address for the X2 network. Possible options:

"DHCP" = The PN/MQTT Coupler tries to get an IP address as well as a gateway and a DNS server in the network via a DHCP server.

"Static IP" = The address, subnet mask and default gateway can be fixed directly in the following fields. The setting of a DNS server can - if required - additionally be done on the web page.

"IP address from web page" = The IP settings of the X2 network can be carried out via the web page. At the first start-up, the PN/MQTT Coupler is only accessible in the X1 network (PROFINET). Only when the IP settings for the X2 network have been set there, the coupler is also accessible via X2 or can establish a connection to the MQTT broker.

Static IP address: If the address mode has been set to "Static IP", the static IP address of the X2 network can be specified here. This setting has no function with "DHCP" and "IP address from web page".

Static IP subnet mask: If the address mode has been set to "Static IP", the subnet mask of the X2 network can be specified here. This setting has no function with "DHCP" and "IP address from web page".

Static IP gateway: If the address mode has been set to "Static IP", the gateway of the X2 network can be specified here. This setting has no function with "DHCP" and "IP address from web page".

Hostname mode: "From PROFINET configuration" or "From webpage".

DHCP hostname: Hostname of the device, is used if the "Hostname mode" option "Take over from PROFINET configuration" was selected.

Webpage: On which network interfaces should the web page be displayed.




NOTE

Please note in the commissioning phase in the PROFINET configuration to activate at least the web page on the PROFINET network side (X1) or "both network sides". Otherwise a complete configuration is not possible.

For security reasons it is advisable to switch off the web pages in the PROFINET configuration after commissioning or at least to switch off the web interface on the network side, which is connected in the WAN or Internet.

7.2 Operating principle of the PN/MQTT coupler

The data exchange between the PLC and the MQTT broker is organized via individual values. A value can be 1, 2 or 4 bytes in size and is in the I/O area of the PROFINET controller. Depending on the data direction, the value is writable to outputs (MQTT Publish) or readable from inputs (MQTT Subscribe).



Up to 100 different values can be exchanged between the PROFINET controller and the MQTT broker (100 slots). The values can be plugged as modules into the slots of the coupler as required.

A module always represents exactly one value, which is exchanged with the broker via its MQTT topic name. A value is usually sent via MQTT in a readable form (direct text or JSON formatted). For this reason, there are different representations for each value size (1, 2, 4, 8 bytes): hexadecimal, unsigned decimal, signed decimal or floating point.


Configuration example:

Slot	Modul	EA	Type	Direction	Topic name (Example)	Value (Example)
1	Output Byte (1 Byte, hex.)	1 Byte Output	Byte	Publish →	"Output QB10"	"0x12"
2	Output Unsigned Int (2 Bytes, dez.)	2 Bytes Outputs	Unsigned Integer	Publish →	"Speed"	"65534"
3	Output Signed dInt (4 Bytes, dez.)	4 Bytes Outputs	Signed double Integer	Publish →	"Output QD14"	"-12345678"
4	Input Word (2 Bytes, hex.)	2 Bytes Inputs	Word	← Subscribe	"Control word"	"0xFFEE"
5	Input Unsigned sInt (1 Bytes, dez.)	1 Byte Inputs	Unsigned short Int	← Subscribe	"Set point"	"255"
6	Input Double Word (4 Bytes, hex.)	4 Bytes Inputs	Double Word	← Subscribe	"Configuration"	"0x11223344"
7	Output Signed Int (2 Bytes, dez.)	2 Bytes Outputs	Signed Integer	Publish →	"Temperature"	"25"
...						

Output modules are sent to the broker once after restarting the coupler and then after each change of the PLC value. If PLC values are sent that change very quickly, it is possible to specify a "publish interval" on the configuration web page.

The value of the input modules is initialized with 0 after (re-)starting the coupler and is permanently taken over into the input area when a new value is received via MQTT. A bit additionally indicates the reception of a value in the PLC.

The value of the input modules is initialized with 0 after restarting the coupler and is permanently taken over into the input area when a new value is received via MQTT. A bit additionally indicates the reception of a value in the PLC.



For each module, the **Topic name** must be defined unambiguously in the module parameters. The name can be chosen suitable to the symbolic name of the PLC value. Up to 40 characters are available. As another parameter, the method of **Quality of Service (QoS)** of the topic can be specified.

Transmission without acknowledge (0): The topic is sent without an acknowledgement from the broker („fire-and-forget“)

Transmission with acknowledge (1): The topic is sent, and an acknowledgement ("PUBACK") is expected from the broker. If no acknowledgement is received, the topic is sent again.

Transmission with acknowledge and confirmation (2): Provides the guarantee that a message has been "delivered exactly once". In order to be able to keep this guarantee, MQTT uses a two-stage acknowledgement of receipt.

Retain: This option tells the broker to save the last message or value in the broker even if the connection to the MQTT client fails.



NOTE


The format of the payload (value representation) of the MQTT messages is explained in chapter 8.3.

7.3 Assign a name to the PN/MQTT coupler

When the configuration of the PN/MQTT coupler is completed in the hardware configurator of the engineering tool, it can be imported into the PLC.

To enable the PN/MQTT Coupler to be found by the PROFINET controller, the PROFINET device name must be assigned to the PN/MQTT Coupler. To do this, use the "Assign device name" function, which you can access with the right mouse button or in the Online menu if the PN/MQTT Coupler is selected.

Use the "Update list" button to search the network for PROFINET stations. With "Assign name" the PROFINET device name can be assigned to the device.



The unique identification of the PN/MQTT coupler is guaranteed here by the MAC address of the device. The PROFINET MAC address can be read on the front of the PN/MQTT Coupler on the left-hand side at X1 ("MAC 1").

If the PN/MQTT coupler has received the correct PROFINET name, it is recognized and configured by the PLC. If the configuration is correct, the PROFINET "BF" LED should be off.

To set the PROFINET name, the Helmholz IPSet Tool can also be used, which can be downloaded free of charge from the Helmholz website or scan the following QR code to download the IPSet Tool.



8 Configuration of MQTT connection

8.1 Access to the web page

As soon as the PN/MQTT coupler has been configured via the PROFINET PLC, the web page of the device is accessible via the PROFINET network. If the IP address is also available on the MQTT network page (static IP, DHCP successful), the web page is also accessible via the MQTT network.



NOTE Please note in the commissioning phase in the PROFINET configuration to activate at least the web page on the PROFINET network side (X1).

When accessing the device for the first time, a password must be assigned for the user "admin" with at least 8 characters. After logging in, you will see the "Overview" view:

PN/MQTT
COUPLER

Helmholz[®]
COMPATIBLE WITH YOU

Overview

MQTT

Module status

System

Overview

PN Configuration X1 (left)

Device name	pnmqttcoupler
Operating mode	Connected
LEDs	SF: ● BF: ● MT: ● PWR: ●
MAC address	24:ea:40:1b:00:20
IP address	172.17.0.82
Port 1 status	Link up, 100 MB/FD
Port 2 status	Link down, -/-

MQTT Configuration X2 (right)

MQTT ClientID	PNMQTTcoupler
Operating mode	Not Connected
LEDs	SF: ● BF: ● MT: ● PWR: ●
MAC address	24:ea:40:1b:00:23
IP address	192.168.128.82
Port 1 status	Link down, -/-
Port 2 status	Link down, -/-

The PN/MQTT Coupler still shows "Bus Error (BF)" on the "Overview" page on the X2 interface in this state because no connection to the MQTT broker has been configured yet.


The error "System error (SF)" on the PROFINET side is also displayed due to the not configured MQTT connection.



NOTE If the web page of the device is not accessible, please check the parameter "Web page" in the PROFINET configuration (see Chap. 7.1), as well as the correct specification of the IP address and subnet mask matching the device with which you call the web page. Please note that the website has an inactivity timeout. If you do not access the website for a while, you will be logged out.

8.2 MQTT basic configuration

After the configuration of the PROFINET side, the connection to the MQTT broker must still be configured on the web page of the PN/MQTT coupler. The configuration can be done in the "MQTT" menu. First select the "IP Settings".



The screenshot shows the MQTT configuration interface. At the top, there are tabs: Overview, MQTT (selected), Module status, and System. A dropdown menu is open under the MQTT tab, showing options: IP Settings (highlighted with a mouse cursor), MQTT Client Settings, Advanced MQTT Settings, MQTT Encryption, and Export/Import Configuration. The main content area is titled "IP Address X2" and contains a form for configuring the IP address of the right network port "X2". The form includes a "Mode" section with radio buttons for "DHCP" (selected) and "Static IP". Below this, there are input fields for "DHCP - Hostname" (PNMQTtcoupler), "New IP address" (192.168.128.82), "New netmask" (255.255.0.0), "New gateway" (192.168.2.250), and "New DNS server address" (192.168.1.8). At the bottom, there is a green button labeled "Update settings".

In the section "IP Address X2" the IP address of the right network port "X2" of the PN/MQTT Coupler is displayed. This can be set if it has not already been received via the PROFINET configuration "Static IP" or via "DHCP".

The MQTT broker is addressed via interface X2. If the MQTT broker is located in the same network as the PROFINET PLC, see note in chapter 5.2.

The necessary information for the connection with the MQTT broker can be made in the "MQTT" menu under "MQTT Client Settings".


MQTT version: The PN/MQTT Coupler supports the MQTT standard "3.1.1" and the new standard "V5". Since the two standards are not compatible, the MQTT version must be set to match the broker.

ClientID: Name of the MQTT client when logging on to a broker

Prefix topic with ClientID: With this option, the ClientID of the device can be preassigned to each topic. The topic name "temperature" then becomes "<ClientID>/temperature".

Username/Password: Authentication at the broker

Broker address: IP address or domain name of the broker. The broker must be in the same subnet as the IP address of the coupler's X2 network.



The screenshot shows the "MQTT Client Settings" form. It contains the following fields and options: "MQTT version" (dropdown menu set to 3.1.1), "ClientID" (text input field with value PNMQTtcoupler), "Prefix topic with ClientID" (toggle switch turned on), "Username" (text input field with value Username), "Password" (text input field with value Password), "Broker address" (text input field with value 192.168.128.42), "Broker MQTT port" (text input field with value 1883), "Keep alive [Seconds]" (text input field with value 60), "Clean session" (toggle switch turned on), "MQTT Payload Data Format" (dropdown menu set to Text), and "Publish interval [0.1s] (0 = as fast as possible)" (text input field with value 0). At the bottom, there is a green button labeled "Update settings".

Broker TCP Port: Port for the MQTT connection to the broker. Common are "1883" for unencrypted and "8883" for TLS encrypted connections.

Keep alive: Time for sending the cyclic life message of the coupler to the broker. If this message is missing, the broker assumes a failure of the coupler.

Clean session (MQTT V3.1.1): Information to the broker upon establishing the connection whether old messages should be deleted or reused.

Clean start (MQTT V5): If Clean Start is enabled, the client and broker must discard existing sessions and start a new session when a connection is established.

If Clean Start is disabled and a session is associated with this client ID, the broker must resume communication with the client based on the status of the session. If no session is associated with this client ID, the broker must create a new session.

Session expiry interval [Seconds] (MQTT 5.0 only): In the context of "Clean start", if "Session expiry interval" is set to 0, the session is terminated when the network connection is closed. Otherwise, the session is kept open until the time expires.

MQTT payload data format:

The value of a topic can be sent in simple text form ("Text") or in structured form ("JSON"). More information about the representation of the values is explained in chapter 8.3.

Publish interval: An MQTT message for a slot is sent automatically as soon as the value changes. If PLC values are to be sent that change very quickly, it is possible to limit the send interval. The Publish interval '0' tells the coupler to send as fast as possible. A number greater than zero tells the coupler not to send faster than $x * 0.1$ seconds.

If all parameters have been set correctly and accepted with "Update settings", the PN/MQTT Coupler should automatically connect to the MQTT broker and the red LEDs should no longer be displayed.

The "Overview" view can be used to check the state:

PN/MQTT
COUPLER

Helmholz
COMPATIBLE WITH YOU

Overview	MQTT	Module status	System																												
<h3>Overview</h3> <div><div><h4>PN Configuration X1 (left)</h4><table><tr><td>Device name</td><td>pnmqtccoupler</td></tr><tr><td>Operating mode</td><td>Connected</td></tr><tr><td>LEDs</td><td>SF: BF: MT: PWR: </td></tr><tr><td>MAC address</td><td>24:ea:40:1b:00:20</td></tr><tr><td>IP address</td><td>172.17.0.82</td></tr><tr><td>Port 1 status</td><td>Link up, 100 MB/FD</td></tr><tr><td>Port 2 status</td><td>Link down, -/-</td></tr></table></div><div><h4>MQTT Configuration X2 (right)</h4><table><tr><td>MQTT ClientID</td><td>PNMQTTCoupler</td></tr><tr><td>Operating mode</td><td>Connected to 192.168.128.42</td></tr><tr><td>LEDs</td><td>SF: BF: MT: PWR: </td></tr><tr><td>MAC address</td><td>24:ea:40:1b:00:23</td></tr><tr><td>IP address</td><td>192.168.128.82</td></tr><tr><td>Port 1 status</td><td>Link up, 100 MB/FD</td></tr><tr><td>Port 2 status</td><td>Link down, -/-</td></tr></table></div></div>				Device name	pnmqtccoupler	Operating mode	Connected	LEDs	SF: BF: MT: PWR: 	MAC address	24:ea:40:1b:00:20	IP address	172.17.0.82	Port 1 status	Link up, 100 MB/FD	Port 2 status	Link down, -/-	MQTT ClientID	PNMQTTCoupler	Operating mode	Connected to 192.168.128.42	LEDs	SF: BF: MT: PWR: 	MAC address	24:ea:40:1b:00:23	IP address	192.168.128.82	Port 1 status	Link up, 100 MB/FD	Port 2 status	Link down, -/-
Device name	pnmqtccoupler																														
Operating mode	Connected																														
LEDs	SF: BF: MT: PWR: 																														
MAC address	24:ea:40:1b:00:20																														
IP address	172.17.0.82																														
Port 1 status	Link up, 100 MB/FD																														
Port 2 status	Link down, -/-																														
MQTT ClientID	PNMQTTCoupler																														
Operating mode	Connected to 192.168.128.42																														
LEDs	SF: BF: MT: PWR: 																														
MAC address	24:ea:40:1b:00:23																														
IP address	192.168.128.82																														
Port 1 status	Link up, 100 MB/FD																														
Port 2 status	Link down, -/-																														

In the next step you can address the I/O data in the PLC program.

8.3 MQTT Payload formats

The value of a topic can be sent in simple text form ("Text") or in structured form ("JSON").

Example for text format:

```
-12345
```

Some MQTT applications expect a structured form in JSON format.

Example for JSON format:

```
{  
  "value": -12345  
}
```

The values are displayed differently depending on the data type:

Type	Size	Format	Presentation
Bit	Bit	Text	„0“/„1“, „off“/„on“, „no“/„yes“, „false“/„true“ (parameterizable, see note)
Byte	1 Byte	Hexadecimal	„0x00“ ... „0xFF“
Unsigned short Int	1 Byte	Decimal	„0“ ... „255“
Signed short Int	1 Byte	Decimal	„-127“ ... „128“
Word	2 Bytes	Hexadecimal	„0x0000“ ... „0xFFFF“
Unsigned Int	2 Bytes	Decimal	„0“ ... „65536“
Signed Int	2 Bytes	Decimal	„-32767“ ... „32787“
Double Word	4 Bytes	Hexadecimal	„0x00000000“ ... „0xFFFFFFFF“
Unsigned double Int	4 Bytes	Decimal	„0“ ... „4294967295“
Signed double Int	4 Bytes	Decimal	„-2147483648“ ... „2147483647“
Real	4 Bytes	Floating point	„-123.456789“ (example)
Long Real	8 Bytes	Floating point	„123456.789999“ (example)



ATTENTION Modules with data type "Bit" occupy a whole byte in the PLC, because PROFINET does not support bits only. Only the lowest bit of the transmitted byte is used.
If a topic of type Bit is received (Topic Subscription) all above mentioned formats are interpreted and the upper/lower case is arbitrary.



NOTE If you need a different representation of the MQTT payload for your application, please contact us. The payload variants are constantly being expanded.

9 Status and control via the PLC

9.1 Status of PN/MQTT Coupler

The PN/MQTT Coupler provides a status (4 bytes) via the PROFINET input image:

Byte/Bit	7	6	5	4	3	2	1	0
Input Byte 0	PROFINET configuration OK	0	PS 1 Voltage available	PS 2 Voltage available	0	0	X2 network IP address available	X2 network cable detected
Input Byte 1	0	0	0	0	0	0	0	MQTT Broker connection active
Input Byte 2	Last MQTT error code (MQTT V5) or Connect Return/Reason-Code							
Input Byte 3	Reserved							

To check the correct function of the PN/MQTT coupler in the PLC, the bit "PROFINET configuration OK" and "MQTT broker connection active" should be read.

9.2 Control of PN/MQTT Coupler

The PN/MQTT coupler can be controlled via the following control bits (1 byte) in the PROFINET output image:

Byte/Bit	7	6	5	4	3	2	1	0
Output Byte 0	Clear MQTT Error Code		-	-	-	-	MQTT Disconnect connection	MQTT lock data exchange

9.3 Subscribe Module

In addition to the input data for the actual value, the subscriber modules additionally have a status byte and a control byte.

Status bits of Subscribe Module:

Byte/Bit	7	6	5	4	3	2	1	0
Input Byte 0	1 = new data received	Receive counter						

Control bits of Subscribe Module:


Byte/Bit	7	6	5	4	3	2	1	0
Output Byte 0	1 = Reset data receive bit	-	-	-	-	-	-	-

To be able to detect the reception of MQTT messages, the receive bit 7 can be used, which must always be reset in the output byte of the module. Alternatively, the receive counter can be checked for changes.

Attention: the receive counter runs until 0x7F and is then reset to 0x00.

10 MQTT encryption and authentication

The transmission between the client and the broker can be encrypted and the devices can authenticate each other, i.e. verify their identity.



Encryption prevents a third party from reading the data. Authentication ensures that only the right devices can exchange data with each other.

In the "MQTT" menu under "MQTT Encryption", encryption can be activated, certificates can be stored, and self-generated certificates can also be created.

The screenshot shows the 'MQTT Encryption Settings' and 'TLS Certificates and Key for MQTT' configuration interface. The 'MQTT Encryption Settings' section includes a dropdown for 'Transport Layer Security (TLS)' set to 'Disabled', a toggle for 'Verify broker certificate (SNTP must be active)' which is turned off, and an 'Update settings' button. Below this is the 'Self-signed certificates / SAS token generator' section, which includes a note about automatic updates, a dropdown for 'Type' set to 'CA, broker, client certificates and keys', and radio buttons for 'Automatically update coupler's CA, certificate and key' set to 'Yes'. There are also input fields for 'Country Name (2 letter code)', 'State or Province Name (full name)', 'Locality Name (e.g. city)', and 'Organization Name (e.g. company)'. The 'TLS Certificates and Key for MQTT' section includes a note to upload certificates and keys, and three 'Browse' buttons for 'CA File (AmazonRootCA1.pem)', 'Client Certificate (854435b24d-certificate.pem.crt)', and 'Client Key (854435b24d-private.pem.key)', followed by a 'Submit' button.

Transport Layer Security (TLS):

Disabled: unencrypted data exchange between client and broker. No certificates or keys are required.

Enabled – Encryption only: Enables encryption without authentication. This option does not require a CA, client certificate or client key.

Encryption + Broker authentication: enables encryption with broker authentication done by the client. With this option, a CA must be uploaded for broker verification (see below).

The screenshot shows the 'MQTT Encryption Settings' configuration interface. The 'Transport Layer Security (TLS)' dropdown is set to 'Encryption + Broker & Client authentication'. The 'Verify broker certificate (SNTP must be active)' toggle is turned on.

Encryption + Broker & Client authentication: enables encryption with mutual broker and client authentication. This option requires a CA and client certificate. In addition to broker verification by the client, the broker can also verify the client as it sends its certificate during the TLS handshake.

Verify broker certificate: Certificates contain an expiration date and must be updated regularly. This option checks whether the broker certificate is still valid.



ATTENTION When using certificates for authentication, time synchronization of the PN/MQTT coupler using SNTP must be enabled.

For encryption and authentication, certificates and keys must be provided (uploaded) to the PN/MQTT Coupler.

CA File: certificate of broker

Client Certificate: Certificate for the PN/MQTT Coupler

Client Key: Private Key File for the PN/MQTT Coupler

TLS Certificates and Key for MQTT

Please upload TLS certificates and key for MQTT.

Browse	CA File (server.crt)
Browse	Client Certificate (coupler.crt)
Browse	Client Key (coupler.key)
Submit	

10.1 Generator for certificates and SAS tokens

For an encrypted and authenticated connection with a broker - whether "on premise" or in the cloud - the certificate of the broker and the certificate of the parent certification authority ('CA') should be downloadable or generated by IT for the own network.







The certificate for the client should then also either be generated by the broker application (example "Amazon IoT", see Chapter 17) or also created by IT.

To make it easier to work with certificates during internal tests, the PN/MQTT Coupler includes a built-in generator for self-signed certificates. For use with Microsoft Azure, a SAS token generator is also available (see Chapter 18).

If an encrypted and authenticated connection is to be established for a test setup with a local broker (e.g. Mosquitto), the PN/MQTT coupler can create the certificates and the private keys both for the PN/MQTT coupler itself and for the broker with the option **"CA, broker, client certificates and keys"**. The certificate of the local certificate authority ('CA') with which the other two certificates were signed is also supplied.

The content of the input fields in the dialog are transferred to the certificates, but they have a more informative character.

After pressing the "Generate and Download" button, the certificates are generated and a ZIP file with the certificates is downloaded:

	broker.crt	21.05.2021 14:06	Sicherheitszertifikat
	broker.key	21.05.2021 14:06	KEY-Datei
	ca.crt	21.05.2021 14:06	Sicherheitszertifikat
	ca.key	21.05.2021 14:06	KEY-Datei
	client.crt	21.05.2021 14:07	Sicherheitszertifikat
	client.key	21.05.2021 14:07	KEY-Datei

The option "Automatically update coupler's CA, certificate and key" transfers the relevant files directly to the PN/MQTT coupler.

In the broker, its private key, certificate and CA file can now also be used.

Self-signed certificates / SAS token generator

Note: If you select an option "Automatically update coupler's CA, certificate and key" CA, client certificate and client key will be automatically used by the coupler

Type CA, broker, client certificates and keys

Automatically update coupler's CA, certificate and key ☒ Yes ☐ No

Country Name (2 letter code) DE

State or Province Name (full name) Deutschland

Locality Name (e.g. city) Grossenseebach

Organization Name (e.g. company) Helmholz GmbH & Co. KG

Organizational Unit Name (e.g. section) Development

CA Common Name Helmholz

Broker Common Name Mosquitto

Client Common Name PNMQTTCoupler

Email Address info@helmholz.de

TLS Certificates and Key for MQTT

Please upload TLS certificates and key for MQTT.

CA File (ca.crt)

Client Certificate (client.crt)

Client Key (client.key)

11 More MQTT settings

Further settings for the MQTT behavior of the PN/MQTT Coupler can be made using the "Advanced MQTT Settings" dialog in the "MQTT" menu.

The screenshot shows the PN/MQTT Coupler web interface. At the top, there's a header with "PN/MQTT COUPLER" and the "Helmholz" logo. Below the header is a navigation bar with tabs: "Overview", "MQTT", "Module status", and "System". The "MQTT" tab is active, and a dropdown menu is open, showing options: "IP Settings", "MQTT Client Settings", "Advanced MQTT Settings" (highlighted with a mouse cursor), "MQTT Encryption", and "Export/Import Configuration". The "Advanced MQTT Settings" dialog is displayed, showing various configuration options for MQTT topics and quality of service (QoS).

PN/MQTT COUPLER **Helmholz**
COMPATIBLE WITH YOU

Overview **MQTT** Module status System

Advanced MQTT Settings

Slots Topic Mode ☒ Individual (From Profinet Settings) ☐ Combined (Single Topic for all Modules)

Combined Publication Topic

Combined Publication Options Quality of Service (QoS): Retain Flag: ☐

Combined Subscription Topic

Combined Subscription Options Quality of Service (QoS):

Last Will Topic

Last Will Message

Last Will Options Quality of Service (QoS): Retain Flag: ☐

Communication Enabled Topic

Communication Enabled Message

11.1 Topic Mode

The topic mode determines how all configured topic messages are sent. Usually, each topic (each configured module) is sent or received individually as an MQTT message Topic Mode "Individual".

The screenshot shows the "Advanced MQTT Settings" dialog. It has a title bar "Advanced MQTT Settings". Below the title bar, there are several configuration options. The "Slots Topic Mode" section has two radio buttons: "Individual (From Profinet Settings)" (selected) and "Combined (Single Topic for all Modules)". The "Combined Publication Topic" field has the value "modules/output". The "Combined Publication Options" section has "Quality of Service (QoS)" set to "0" and "Retain Flag" set to "Off". The "Combined Subscription Topic" field has the value "modules/input". The "Combined Subscription Options" section has "Quality of Service (QoS)" set to "0".

Advanced MQTT Settings

Slots Topic Mode ☒ Individual (From Profinet Settings) ☐ Combined (Single Topic for all Modules)

Combined Publication Topic

Combined Publication Options Quality of Service (QoS): Retain Flag: ☐

Combined Subscription Topic

Combined Subscription Options Quality of Service (QoS):

For certain applications, e.g. to connect to the Microsoft Azure Cloud (see Chapter 18), a device may only send or receive all data under one MQTT message Topic Mode "Combined".

For the Combined use case, the Topic Name for Publishing and the Topic Name for Subscription can be specified in the following settings, along with the associated QoS and Retain property.

Example of Topic Mode "Individual":

Message 1 for Topic „temperature“

```
{
  "value": 23
}
```

Message 2 for Topic „humidity“:

```
{
  "value": 40
}
```

Example for Topic Mode "Combined":

Message for Topic „modules/output“

```
{
  "temperature": 23
  "humidity": 40
}
```



HINWEIS If you need a different representation of the MQTT payload for your application, please contact us. The payload variants are constantly being expanded.

11.2 Last Will Message

The "Last Will Message" is an MQTT message to inform other clients about an improperly disconnected client. The PN/MQTT coupler sends its "last will" message to the broker when it connects to the broker.

Last Will Topic	<input type="text" value="pn-coupler-status"/>
Last Will Message	<input type="text" value="I am Offline!"/>
Last Will Options	Quality of Service (QoS): <input type="text" value="1"/> Retain Flag: <input checked="" type="checkbox"/>

The "last will" message is a normal MQTT message with an arbitrary topic and payload. The broker stores the message until it detects that the client has involuntarily disconnected. In response to the unforeseen disconnection, the broker sends the "last-will" message to all subscribed clients of the "last-will" topic.

If the client disconnects properly, the broker discards the stored "Last Will Message".

11.3 „Communication Enable“ and „Communication Stopped“ messages

The "Communication Enable" message is always sent by the PN/MQTT coupler when the coupler is ready for operation. For this the coupler must be configured via PROFINET and the PLC must be in RUN.

The "Communication Stopped" message is always sent by the PN/MQTT coupler when the coupler is no longer ready for operation. Reasons for this are a network interruption, a reconfiguration of the device or if the PLC has stopped.

Communication Enabled Topic	<input type="text" value="Communication-status"/>	
Communication Enabled Message	<input type="text" value="Enabled"/>	
Communication Enabled Options	Quality of Service (QoS): <input type="text" value="0"/>	Retain Flag: <input checked="" type="checkbox"/>
Communication Stopped Topic	<input type="text" value="Communication-status"/>	
Communication Stopped Message	<input type="text" value="Stopped"/>	
Communication Stopped Options	Quality of Service (QoS): <input type="text" value="0"/>	Retain Flag: <input type="checkbox"/>

12 Further functions in the web interface

12.1 Module status


On the web page "Module status" the configured module configuration and the current IO data are displayed. If there is a configuration error, the error is displayed in the "Diagnostic message" column.

Module Configuration				
	Module Type	PN Configuration X1 (left)	MQTT Configuration X2 (right)	Diagnostic message
Slot#: 0	PN/MQTT Coupler	IN 4 Bytes (0xB3 01 00 00) / OUT 1 Byte (0x00)	Control Bits (0x00) / Status Register (0xB3 01 00 00)	
Slot#: 1	Output Byte	OUT 1 Byte (0x00)	PUBLISH: "Output_Byte_QB101" (0x00), QoS=1, Retain=False	
Slot#: 2	Output Unsigned short Int	OUT 1 Byte (0x00)	PUBLISH: "Output_Unsigned_sint_QB102" (0x00), QoS=0, Retain=False	
Slot#: 3	Output Signed short Int	OUT 1 Byte (0x00)	PUBLISH: "Output_Signed_sint_QB103" (0x00), QoS=0, Retain=False	
Slot#: 4	Output Word	OUT 2 Bytes (0x00 00)	PUBLISH: "Statusword" (0x00 00), QoS=0, Retain=False	
Slot#: 5	Output Unsigned Int	OUT 2 Bytes (0x00 00)	PUBLISH: "Output_UnsignedInt_QW112" (0x00 00), QoS=0, Retain=False	
Slot#: 6	Output Signed Int	OUT 2 Bytes (0x00 00)	PUBLISH: "Temperature" (0x00 00), QoS=1, Retain=False	
Slot#: 7	Output double Word	OUT 4 Bytes (0x00 F7 6B 5A)	PUBLISH: "Out_DoubleWord_QD120" (0x00 F7 6B 5A), QoS=0, Retain=False	
Slot#: 8	Output Unsigned double Int	OUT 4 Bytes (0x00 00 00 00)	PUBLISH: "Out_Unsigned_dint_QD124" (0x00 00 00 00), QoS=0, Retain=False	
Slot#: 9	Output Signed double Int	OUT 4 Bytes (0x00 00 00 00)	PUBLISH: "Out_Signed_dint_QD128" (0x00 00 00 00), QoS=0, Retain=False	
Slot#: 10	Output Unsigned double Int	OUT 4 Bytes (0x00 F7 6B 5A)	PUBLISH: "Milliseconds" (0x00 F7 6B 5A), QoS=0, Retain=False	
Slot#: 11	Output Unsigned double Int	OUT 4 Bytes (0x00 ED 01 39)	PUBLISH: "Cycle counter" (0x00 ED 01 39), QoS=1, Retain=False	
Slot#: 12	Input Byte	IN 2 Bytes (0x00 00) / OUT 1 Byte (0x00)	SUBSCRIBE: "Input_Byte_IB200" (0x00) / Control (0x00) / Status (0x00)	
Slot#: 13	Input Word	IN 3 Bytes (0x00 00 00) / OUT 1 Byte (0x00)	SUBSCRIBE: "Controlword" (0x00 00) / Control (0x00) / Status (0x00)	

12.2 Export/Import of the configuration

The settings made on the web page can be saved on the PC in an editable format for backup, for series production or for manual editing of the device configuration (download).

If required, the file for configuring a device can then be uploaded again.



12.3 Account

In the menu "System" under "Account" the password of the user "admin" can be changed.

The screenshot shows the 'System' menu with 'Account' selected. The 'Change password' form includes a note: 'New password must be at least 8 characters long.' The form has three input fields: 'Login' (containing 'admin'), 'New password', and 'Repeat password'. Below the fields are two buttons: 'Submit' (with a checkmark icon) and 'Log out' (with a circular arrow icon).

Currently the PN/MQTT Coupler contains only this user, the name is not changeable.

12.4 Upload TLS certificates for HTTPS

For secure access to the PN/MQTT Coupler website, a company certificate can be stored in the "System" menu under "HTTPS Certificates".

This ensures that the call to the PN/MQTT Coupler configuration web page is trusted in addition to HTTPS encryption.

The screenshot shows the 'TLS Certificate and Key for HTTPS' form. It includes a note: 'Please upload TLS certificate and key. Maximum allowed key length is 2048 bits.' There are two 'Browse' buttons (with magnifying glass icons) for uploading a certificate and a key. Below these are two text input fields with placeholder text: 'Upload certificate e.g (my_c)' and 'Upload Key e.g (my_key.ke)'. At the bottom is a green 'Submit' button with a checkmark icon.

12.5 SNTP Settings

The PN/MQTT coupler can update its time via the MQTT network interface (X2) using the SNTP protocol. The time is used for checking the Certificates, logging or for timestamps in the MQTT topics.

The screenshot shows the 'SNTP Settings' form. It includes three input fields: 'NTP server or pool address' (containing 'pool.ntp.org'), 'Query interval' (with 'Days' and 'Hours' sub-fields, both set to 0), and 'Timezone' (a dropdown menu set to 'Europe/Berlin'). At the bottom is a green 'Update settings' button with a checkmark icon.

12.6 Firmware update

The firmware of the PN/MQTT Coupler can be updated very easily via the website. You can obtain the firmware from the Helmholtz website at www.helmholz.de.


Link to latest firmware:

<http://www.helmholz.de/goto/700-162-3MQ02#tab-software>

The firmware file can be recognized by the file extension "HUF" (Helmholz Update File) and is encrypted to protect it from modification.



Overview	MQTT	Module status	System
<h3>Firmware update</h3> <div><input type="button" value="Browse"/> <input type="button" value="Upload firm"/></div> <div><input type="button" value="Submit"/></div> <p>Currently installed firmware version is V1.03.003. The latest firmware update file can be found on here.</p> <p>ATTENTION! Please note that the Device will be unavailable during update procedure. Communication with other devices will be interrupted or stopped.</p>			<div>Account</div> <div>HTTPS Certificates</div> <div>SNTP Settings</div> <div>Syslog Local</div> <div>Syslog Remote</div> <div>Firmware Update</div> <div>Factory Reset</div>



Place the firmware file on your PC and select the storage location with "Browse" and start the firmware update with "Submit". The firmware file is then transferred, decrypted and checked. If the content is correct, the firmware is burned into the program memory and the PN/MQTT Coupler is restarted.



ATTENTION During the update process the operation of the PN/MQTT Coupler is interrupted. Do not switch off the device during the update process!



NOTE The configuration of the PN/MQTT Coupler will be kept when updating to a higher version, as far as it is technically possible. However, a "downgrade" to an older firmware version can lead to configuration errors. It is recommended to perform a factory reset after a downgrade.

12.7 Reset to factory settings

Resetting the PN/MQTT Coupler to factory settings can be performed via the website or via the PROFINET function.

When resetting the PN/MQTT Coupler, the configuration is irretrievably deleted and the settings are set to the delivery state. The firmware remains at the current state.





ACHTUNG Please note that the device is no longer available in the network after resetting to factory settings. The PROFINET name and IP addresses are deleted, communication with the PLC is stopped and the PLC detects a configuration error and may also go to stop.

12.7.1 Reset to factory settings via website

Select the "Factory Reset" menu item in the "System" menu.


Press the button "Set factory defaults and reboot" and confirm the security prompt.



12.7.2 Reset to factory settings via "IPSet" tool

To reset the PN/MQTT Coupler to factory settings, the Helmholz tool "IPSet" can also be used via the PROFINET network.

The Helmholz IPSet Tool can be downloaded free of charge from the Helmholz website at the product or scan the QR code.



13 Diagnosis via LEDs

	X1 PROFINET (left side)	X2 MQTT network (right side)
SF (red)		
Off	Configuration correct	Configuration correct
On	PROFINET diagnostic alarm pending	PROFINET side not configured or failed
Flashing	PROFINET function "LED flashing" for finding the device is executed	-
BF (red)		
Off	Connection to PROFINET controller is established	MQTT broker connection is active
On	The device has no configuration, the PROFINET device name is incorrect, or there is no connection with the PROFINET controller	No connection to the MQTT broker can be established
Flashing	PROFINET function "LED flashing" for finding the device is executed	-
MT (yellow)		
Flashing	A firmware update is being carried out	A firmware update is being carried out
Flashing with SF and BF	PROFINET function "LED flashing" for finding the device is being carried out	-
PWR (green)		
On	PS1 Power supply present	PS2 Power supply present
RUN (green)		
Off	Firmware or device defective. Please contact Support	
On	The device is ready to operate	
RJ45 LEDs	X1 P1/P2 und X2 P1/P2	
Green (Link)	Connected	
Orange (Act)	Data transfer at the port active	

14 Client tools for MQTT data exchange


In order to be able to test the data exchange via the PN/MQTT coupler when the application is not yet available on the other side or to be able to observe the data sent by the PN/MQTT coupler next to the application, the use of MQTT client test programs is recommended. In this chapter 3 MQTT clients are presented as examples, but there are many more tools.

14.1 MQTT Explorer

The "MQTT Explorer" by Thomas Nordquist (<http://mqtt-explorer.com/>) is a very practical little tool for Windows, Mac and Linux.

Besides a tidy interface, hierarchical display of topics and the possibility to display values in graphs, the program works very fast and is compact.


GitHub: [↗](#)



14.2 MQTT.fx V5


MQTT.fx offers a very extensive range of functions in the paid version from version V5.

In particular, the extensible payload decoders facilitate the testing with MQTT.



14.3 MQTT Box

MQTT Box (<http://workswithweb.com/mqttbox.html>) is easily installable as a Linux, Macintosh or Windows APP.



15 Application example „mosquitto“

Eclipse Mosquitto (mosquitto.org) is an open source MQTT broker for MQTT V3.1.1 and MQTT V5.



Mosquitto is available for Linux - including the Raspberry PI - as well as for the PC. The Mosquitto project also includes a command line MQTT client for testing.

15.1 Mosquitto Test-Host


Eclipse Mosquitto operates a Mosquitto test broker at test.mosquitto.org.

The test broker can be addressed with MQTT V3.1.1 as well as with MQTT V5.

The easiest way to reach the test broker is unencrypted (port 1883).

Details on usage are explained on the Mosquitto test broker website [↗](#).

Note: To be able to resolve the domain name of the test broker, a valid DNS server must be specified in the IP settings!

A screenshot of the "MQTT Client Settings" form. The form has a light gray background and a white border. It contains the following fields and controls: "MQTT version" (dropdown menu set to "5.0"), "ClientID" (text input field containing "PNMQTTCoupler"), "Prefix topic with ClientID" (toggle switch turned off), "Username" (text input field containing "Username"), "Password" (text input field containing "Password"), "Broker address" (text input field containing "test.mosquitto.org"), "Broker MQTT port" (text input field containing "1883"), "Keep alive [Seconds]" (text input field containing "60"), "Clean start" (toggle switch turned on), "Session expiry interval [Seconds]" (text input field containing "0"), "MQTT Payload Data Format" (dropdown menu set to "Text"), and "Publish interval [0.1s] (0 = as fast as possible)" (text input field containing "5").

15.2 Install and use Mosquitto locally

Mosquitto can run on Linux, on a Windows PC (64-bit and 32-bit) and on a Macintosh. A wide variety of derivatives are supported under Linux: Raspberry PI, Debian, Ubuntu, etc.

The corresponding packages can be downloaded here [↗](#) or installed with a package manager.

16 Application example „HiveMQ“

HiveMQ (<https://www.hivemq.com>) is a professional, scalable MQTT broker that runs both locally on the PC (Windows or Linux) and can be used in the cloud with high performance and high availability. HiveMQ can be used as a broker between the device layer and the cloud applications (AWS, Azure, SAP, etc.).



HiveMQ is available in 3 variants: "Community" (open source on GitHub), "Professional" and "Enterprise". The last two versions can be run on your own servers (on premise) or used as a cloud service by HiveMQ.

16.1 Use of HiveMQ in a virtual machine


An "out-of-the-box" trial version of the enterprise version HiveMQ solution can be downloaded and launched at <https://www.hivemq.com/downloads/>. The version can be launched on Windows, Linux. A Docker version or a variant that can be launched directly in AWS is also available.

The trial version can be accessed directly from the PN/MQTT coupler under the IP address of the PC under which it was started.

The MQTT port 1833 is active, no encryption or "user/password" is used.

```
run.bat - Verknüpfung
-----
HIVEMQ_HOME: "C:\Users\cabo\Desktop\hivemq-4.5.1"
JAVA_OPTS: -XX:+HeapDumpOnOutOfMemoryError -XX:HeapDumpPath="C:\Users\cabo\Desktop\hivemq-4.5.1\heap-dump.hprof" -Dcom.sun.management.jmxremote -Dcom.sun.management.jmxremote.port=9010 -Dcom.sun.management.jmxremote.local.only=false -Dcom.sun.management.jmxremote.authenticate=false -Dcom.sun.management.jmxremote.ssl=false -Djava.net.preferIPv4Stack=true -noovrify --add-opens java.base/java.lang=ALL-UNNAMED --add-opens java.base/java.nio=ALL-UNNAMED --add-opens java.base/sun.nio.ch=ALL-UNNAMED --add-opens java.base/sun.security.provider=ALL-UNNAMED --add-opens jdk.management/com.sun.management.internal=ALL-UNNAMED --add-exports java.base/jdk.internal.misc=ALL-UNNAMED
JAVA_VERSION: 11.0.10
-----
2021-03-15 10:24:10,129 INFO - Starting HiveMQ Enterprise Server
2021-03-15 10:24:10,144 INFO - HiveMQ Version: 4.5.1
2021-03-15 10:24:10,144 INFO - HiveMQ home directory: C:\Users\cabo\Desktop\hivemq-4.5.1
2021-03-15 10:24:10,144 INFO - Log Configuration was overridden by C:\Users\cabo\Desktop\hivemq-4.5.1\conf\logback.xml
2021-03-15 10:24:10,550 INFO - This node's ID is CFFA1
2021-03-15 10:24:10,550 INFO - Clustering is disabled
2021-03-15 10:24:18,543 INFO - No valid license file found. Using trial license, restricted to 25 connections.
2021-03-15 10:24:20,968 INFO - This node uses 4 CPU cores.
2021-03-15 10:24:20,983 INFO - Starting HiveMQ extension system.
2021-03-15 10:24:21,077 WARN - #####
# This HiveMQ deployment is not secure! You are lacking Authentication and Authorization. #
# Right now any MQTT client can connect to the broker with a full set of permissions. #
# For production usage, add an appropriate security extension and remove the hivemq-allow-all extension. #
# You can download security extensions from the HiveMQ Marketplace (https://www.hivemq.com/extensions/). #
#####
2021-03-15 10:24:21,093 INFO - Extension "Allow All Extension" version 1.0.0 started successfully.
2021-03-15 10:24:23,673 INFO - CFFA1: no members discovered after 2033 ms: creating cluster as first member
2021-03-15 10:24:23,713 INFO - No user for HiveMQ Control Center configured. Starting with default user
2021-03-15 10:24:24,151 INFO - Starting HiveMQ Control Center on address 127.0.0.1 and port 8080
2021-03-15 10:24:24,151 INFO - Control Center Audit Logging started.
2021-03-15 10:24:24,151 INFO - Started HiveMQ Control Center in 454ms
2021-03-15 10:24:24,167 INFO - Starting TCP listener on address 0.0.0.0 and port 1883
2021-03-15 10:24:24,308 INFO - Started TCP listener on address 0.0.0.0 and on port 1883
2021-03-15 10:24:24,308 INFO - Started HiveMQ in 14172ms
```

The trial version also includes an extensive information web page.




16.2 HiveMQ Cloud

At <https://www.hivemq.com/cloud/>, an account can be created for the HiveMQ Cloud and own "clusters" (MQTT brokers) can be operated.

HiveMQ offers the setup of a free cluster in the "Free" model for testing and small use cases.


In addition, a professional cluster with full functionality can be tested free of charge for a few days in the "Starter" model.


 **BASIC**
Perfect for testing and small use cases


FREE
no credit-card required


- ✓ Connect up to 100 IoT devices
- ✓ 10 GB data traffic / month included
- ✓ up to 3 days data retention time
- ✓ No uptime guarantee
- ✓ Community Support

[CREATE CLUSTER](#)

[Home](#)


[Clusters](#)



[Billing](#)


[Help](#)


[Give Feedback](#)

Your Clusters

[REFRESH](#)[CREATE NEW CLUSTER](#)

 **STARTER**
Name: e619db7591d8456fb00acf7079b56cc7

URL
e619db7591d8456fb00acf7079b56cc7.env-1.hivemq.cloud

Port (TLS)
8883

[MANAGE CLUSTER](#)

STATUS
Running


Started
15-03-2021 16:37:30

[CONTROL CENTER](#)

[Free Trial](#)

You can access the "Cluster Detail" via "Manage Cluster". In this dialog, click the "Credentials" tab to create a new MQTT client access ("Username"/"Password") under "MQTT Credentials" with "Add".

Cluster Detail

 **STARTER**
Name: e619db7591d8456fb00acf7079b56cc7

[Free Trial](#)[X](#)

[Overview](#)[Integrations](#)[Credentials](#)

MQTT Credentials

[Add New Credentials](#)

Username
username

Password
password

Confirm
confirm

[+ ADD](#)

[Current Credentials](#)

Username	Password	Actions
cbokholt	*****	X

Herewith all necessary settings are already done and the PN/MQTT Coupler can access the HiveMQ Broker.

In the PN/MQTT Coupler, the following settings must now be applied under "MQTT Client Settings":

MQTT Client Settings

MQTT version	5.0
ClientID	PNMQTTcoupler
Prefix topic with ClientID	<input type="checkbox"/>
Username	pnmqtt
Password	*****
Broker address	3cdf0aa971b94774a866035875d9adc3.s1.eu.hivemq
Broker MQTT port	8883
Keep alive [Seconds]	60
Clean start	<input checked="" type="checkbox"/>
Session expiry interval [Seconds]	0
MQTT Payload Data Format	Text
Publish interval [0.1s] (0 = as fast as possible)	5

HiveMQ supports both **MQTT version** 3.1.1 and version 5.

The **ClientID** can be any.

Under **Username** and **Password**, accept the values entered in the MQTT Credentials.

Under **Broker address** copy the HiveMQ URL.

Set **Broker Port** to 8883.


The remaining settings can be selected as desired.

MQTT Encryption Settings

Transport Layer Security (TLS)	Encryption + Broker authentication
Verify broker certificate (SNTP must be active)	<input type="checkbox"/>


Transport Layer Security (TLS) must be set to "Encryption + Broker authentication".

The Control Center of the HiveMQ cluster provides a comprehensive overview of all information of the MQTT broker:




17 Application example „Amazon IoT Core“

The PN/MQTT Coupler makes it very easy to transfer data directly to the Amazon Cloud (AWS). The AWS IoT Core component is an MQTT broker in the AWS Cloud. MQTT messages can be sent directly to AWS IoT Core and then processed in the other AWS services.




In your AWS account, open the Internet of Things / IoT Core module.




17.1 Create a policy

Create a new device policy (set of rules for access rights) for the PN/MQTT Coupler under "Secure/Policies" and assign a name for the policy.




Give the policy a name and enter "iot:*" for Action, "*" for Resource ARN and check "Allow" for Effect. Switch to the "Advanced mode" and check the display:



```
1 {
2   "Version": "2012-10-17",
3   "Statement": [
4     {
5       "Effect": "Allow",
6       "Action": "iot:*",
7       "Resource": "*"
8     }
9   ]
10 }
```


This will give you full access to "Subscriptions" and "Publications" (can be customized later).

Now click at the bottom right on .




17.2 Create „AWS IoT Things“

Under “Manage/Things”, select “Create a single thing”.




Give the “Thing” a name.

The other fields on this page are not relevant for now.



In the next dialog, select "Create certificate".



Download "certificate for this Thing", "public key" and "private key" and keep them in a safe place, they cannot be reloaded.

Certificate created!

Download these files and save them in a safe place. Certificates can be retrieved at any time, but the private and public keys cannot be retrieved after you close this page.

In order to connect a device, you need to download the following:

A certificate for this thing	8575c2d4c4.cert.pem	Download
A public key	8575c2d4c4.public.key	Download
A private key	8575c2d4c4.private.key	Download

You also need to download a root CA for AWS IoT:
A root CA for AWS IoT [Download](#)

[Activate](#)

[Cancel](#)[Done](#)[Attach a policy](#)

Additionally, download the root certificate ("root CA") from AWS. For this sample application, use the "RSA 248 bit key Amazon Root CA 1".

CA certificates for server authentication

Depending on which type of data endpoint you are using and which cipher suite you have negotiated, AWS IoT Core server authentication certificates are signed by one of the following root CA certificates:

VeriSign Endpoints (legacy)

- RSA 2048 bit key: [VeriSign Class 3 Public Primary G5 root CA certificate](#)

Amazon Trust Services Endpoints (preferred)

Note

You might need to right click these links and select **Save link as...** to save these certificates as files.

- RSA 2048 bit key: [Amazon Root CA 1](#)
- RSA 4096 bit key: Amazon Root CA 2. Reserved for future use.
- ECC 256 bit key: [Amazon Root CA 3](#)
- ECC 384 bit key: Amazon Root CA 4. Reserved for future use.

Now click the "Activate" button and then "Attach policy".

In order to connect a device, you need to download the following:


A certificate for this thing	8575c2d4c4.cert.pem	Download
A public key	8575c2d4c4.public.key	Download
A private key	8575c2d4c4.private.key	Download

You also need to download a root CA for AWS IoT:
A root CA for AWS IoT [Download](#)


[Activate](#)

[Cancel](#)[Done](#)[Attach a policy](#)

Select the policy created at the beginning and create the device with "Register Thing".




The device now appears in the list of "Things".



Click on the device and select "Interact" in the next dialog.

Copy the access URL ("Thing Shadow Endpoint") for this device.



17.3 Configure PN/MQTT Coupler for AWS Access

Configure the PN/MQTT coupler in the PROFINET engineering tool (e.g. TIA Portal) as described in chapter 7. When parameterizing the MQTT Topic modules, note that AWS only supports QoS '0' and '1' and that no "Retain" flag may be set for the Publisher modules!



ATTENTION AWS IoT Core has some limitations with the MQTT messages:

1. the "Retain Flag" must not be used!
2. "QoS 2" cannot be used with AWS!
3. "Keep-alive" must be between 30 and 1200 seconds!

To connect to AWS IoT Core, it is mandatory to specify a gateway and DNS server in the IP Settings.

On the PN/MQTT Coupler website, the following settings must now be made in the "MQTT" menu under "MQTT Client Settings":

AWS IoT Core currently only supports **MQTT version 3.1.1**.

The **ClientID** can be any.

Username and **password** are not required.


At **Broker address**, the endpoint URL copied on the previous page must be pasted.

The **Broker port** must be set to 8883.

Keep alive must be set between 30 and 1200 seconds for AWS.

Transport Layer Security (TLS) must be set to "Encryption + Broker & Client authentication".

Use the certificates downloaded on page 46 in the TLS Certificates dialog:



For the CA file, use the "AmazonRootCA1.pem" file.

MQTT Client Settings

MQTT version	3.1.1
ClientID	PNMQTTCoupler
Prefix topic with ClientID	<input type="checkbox"/>
Username	Username
Password	Password
Broker address	a3b8mq51kznrk-ats.iot.eu-central-1.amazonaws.com
Broker MQTT port	8883
Keep alive [Seconds]	60
Clean session	<input checked="" type="checkbox"/>
MQTT Payload Data Format	Text
Publish interval [0..1s] (0 = as fast as possible)	5

MQTT Encryption Settings

Transport Layer Security (TLS)	Encryption + Broker & Client authentication
Verify broker certificate (SNTP must be active)	<input checked="" type="checkbox"/>

TLS Certificates and Key for MQTT

Please upload TLS certificates and key for MQTT.

<input type="button" value="Browse"/>	CA File (AmazonRootCA1.pem)
<input type="button" value="Browse"/>	Client Certificate (854435b24d-certificate.pem.crt)
<input type="button" value="Browse"/>	Client Key (854435b24d-private.pem.key)
<input type="button" value="Submit"/>	


The client certificate is the "xxx-certificate.pem.crt" file, it contains both the certificate and the public key of the client.

The last thing you need is the private key of the client ("xxx-private.pem.key").


This completes the configuration and the PN/MQTT Coupler should connect to the AWS IoT Core.

17.4 Testing the MQTT Connection in AWS

To check whether the data exchange with the PN/MQTT Coupler works via MQTT, MQTT Test Client can be called in the AWS IoT Core. Under "Thing", select the configured PN/MQTT Coupler. Then select "Activity" from the menu on the left, and you will find the "MQTT Client" button on the top right.



In the following dialog you can activate the display of a topic sent by the PN/MQTT coupler under "Subscribe to a topic" and send data to the PN/MQTT coupler under "Publish to a topic".



AWS IoT
MQTT test client

MQTT test client Info

You can use the MQTT test client to monitor the MQTT messages being passed in your AWS account. Devices publish MQTT messages that are identified by topics to communicate their state to AWS IoT. AWS IoT also publishes MQTT messages to inform devices and apps of changes and events. You can subscribe to MQTT message topics and publish MQTT messages to topics by using the MQTT test client.

Subscribe to a topic

Publish to a topic

Topic name

The topic name identifies the message. The message payload will be published to this topic with a Quality of Service (QoS) of 0.

Message payload

► Additional configuration

Publish

Subscriptions	Temperature	Pause	Clear	Export	Edit
<div> <input type="checkbox"/> Milliseconds <input type="checkbox"/> </div> <div> <input checked="" type="checkbox"/> Temperature <input type="checkbox"/> </div>	<div> ▼ Temperature </div> <div> 1234 </div>				

If the test is successful, the configuration is complete!




ATTENTION For the connection with amazon AWS, it is mandatory to specify a gateway and a DNS server in the IP settings. To check that the certificates are up to date, activate time synchronization via SNTP.

18 Application example „Microsoft Azure“

18.1 Create device in Azure

Under Microsoft Azure, an IoT Hub must first be created.




Choose an appropriate subscription. For a new AWS account, the "Free Trial" can be used if applicable.


The IoT Hub name can be chosen arbitrarily.

In the next dialog, the details can be checked again and "Create" starts the deployment of the IoT Hub component in Azure.

Deployment may take a few minutes.



Then select the newly created IoT Hub.



Home > IoT Hub

IoT Hub Helmholz GmbH & Co. KG


+ Create Manage view Refresh Export to CSV Open query Feedback Assign tags

Filter for any field... Subscription == all Resource group == all Location == all Add filter

Showing 1 to 1 of 1 records. No grouping List view

Name	Type	Resource group	Location	Subscription
HelmholzIoT	IoT Hub	Test	Germany West Central	Azure-Abonnement 1

In the menu tree, select "IoT devices" at the bottom left and create a new device with "New" at the top.



Home > IoT Hub > HelmholzIoT

HelmholzIoT | IoT devices

Search (Ctrl+/) << + New Refresh Delete

View, create, delete, and update devices in your IoT Hub.

Field Operator Value

+ × select or enter a property name = specify constraint value

+ Add a new clause

Query devices Switch to query editor

Device ID	Status	Last Status Update (UTC)	Authentication Type	Cloud to Device Message ...
No devices found				

Settings

- Shared access policies
- Identity
- Pricing and scale
- Networking
- Certificates
- Built-in endpoints
- Failover
- Properties
- Locks

Explorers

- Query explorer
- IoT devices**

In the following dialog you can give the device a device ID.

The other settings can be used unchanged, important are the options "Symmetric key" and Generate key automatically.

Home > IoT Hub > HelmholtzIoT >

Create a device

Find Certified for Azure IoT devices in the Device Catalog

Device ID *

Authentication type ☒ Symmetric key ☐ X.509 Self-Signed ☐ X.509 CA Signed

Primary key

Secondary key

Auto-generate keys ☒

Connect this device to an IoT hub

Parent device **No parent device**
[Set a parent device](#)

+ New Refresh Delete

View, create, delete, and update devices in your IoT Hub.

Field	Operator	Value
<input type="text" value="select or enter a property name"/>	<input "="" type="text" value="="/>	<input type="text" value="specify constraint value"/>

+ Add a new clause

[Switch to query editor](#)

Device ID	Status	Last Status Update (UTC)	Authentication Type	Cloud to Device Message Count
PNMQTTCoupler	Enabled	--	Sas	0

Select the device.

Home > IoT Hub > HelmholtzIoT >

PNMQTTCoupler

HelmholtzIoT

Device ID

Primary Key

Secondary Key

Primary Connection String

Secondary Connection String

Enable connection to IoT Hub ☒ Enable ☐ Disable

Parent device **No parent device**

Copy the "Primary Connection String" to the clipboard.

18.2 Configure PN/MQTT Coupler for Azure

The PN/MQTT coupler must already be configured via PROFINET and have an IP address on the MQTT network side and be able to establish a connection to the Internet (gateway and DNS server are available).

First, an "Azure SAS Token" must be created for the coupler in the PN/MQTT Coupler in the "MQTT" menu under "MQTT Encryption".

Self-signed certificates / SAS token generator

Note: If you select an option "Update MQTT configuration from connection string" MQTT client id, username and password will be changed and Baltimore CyberTrust Root CA will be used for CA File

Type

Azure SAS token

Update MQTT configuration from connection string

☒ Yes ☐ No

Azure connection string

HostName=HelmholzIOT.azure-devices.net;DeviceId=PNMQTTCou

Expiration date

26.05.2022

Expiration time

12:00

Generate and download

The "Primary connection string" from the clipboard (see previous page) must be entered as the "Azure connection string". As "Expiration date" and "Expiration time" a time in the future must be entered.

With "Update MQTT configuration from connection string", the connection settings are automatically transferred to the "MQTT Settings". This includes "Username", "Password" and the "Broker address".

In the "MQTT Client Settings", check the remaining settings as shown on the right. The broker port must be set to 8883.

The MQTT Encryption must be set to "Encryption + Broker authentication".

MQTT Encryption Settings

Transport Layer Security (TLS)

Encryption + Broker authentication

Verify broker certificate (SNTP must be active)

☐

MQTT Client Settings

MQTT version

3.1.1

ClientID

PNMQTTCoupler

Prefix topic with ClientID

☐

Username

HelmholzIOT.azure-devices.net/PNMQTTCoupl

Password

.....

Broker address

HelmholzIOT.azure-devices.net

Broker MQTT port

8883

Keep alive [Seconds]

60

Clean session

☒

MQTT Payload Data Format

JSON

Publish interval [0.1s] (0 = as fast as possible)

2

Since Microsoft Azure can only receive one central topic from each device, all configured values from the PLC must be sent together in a combined topic.

Select "MQTT / Advanced MQTT settings" and check whether the "Combined Topic mode" is activated.

Advanced MQTT Settings

Slots Topic Mode

☐ Individual (From Profinet Settings) ☒ Combined (Single Topic for all Modules)

Combined Publication Topic

devices/PNMQTTCoupler/messages/events/

Combined Publication Options

Quality of Service (QoS): 0

Retain Flag: ☐

Combined Subscription Topic

devices/PNMQTTCoupler/messages/devicebound/#

Combined Subscription Options

Quality of Service (QoS): 0

The "Combined Publication Topic" must be set to the following format for Microsoft Azure:

`devices/<device-ID>/messages/events/`

The "Combine Subscription Topic" must be set to the following format for Microsoft Azure:

`devices/<device-ID>/messages/devicebound/#`

The <device-ID> of the device created in Azure must be specified correctly here, e.g.:

`devices/PNMQTTCoupler/messages/events/`

If all settings are correct, the PN/MQTT Coupler should establish the connection to Microsoft Azure by itself.

MQTT Configuration X2 (right)	
MQTT ClientID	PNMQTTCoupler
Operating mode	Connected to HelmholtzIoT.azure-devices.net
LEDs	SF: <input type="checkbox"/> BF: <input type="checkbox"/> MT: <input type="checkbox"/> PWR: <input checked="" type="checkbox"/>
MAC address	24:ea:40:1b:00:7f
IP address	192.168.20.30
Port 1 status	Link up, 100 MB/FD
Port 2 status	Link down, -/-



ACHTUNG Microsoft Azure has some restrictions:


1. the "Retain flag" must not be used!
2. "QoS = 2" cannot be used with Azure!
3. keep alive is limited to a maximum of 19 min (1140 seconds).
4. "Communication enable" & "Communication stopped" messages must not be used.

For the connection with Microsoft Azure, it is mandatory to specify a gateway and a DNS server in the IP settings.

Time synchronization via SNTP must be activated to check whether the certificates are up-to-date.

18.3 Checking the data transfer in Microsoft Azure

Whether there is an active connection of the PN/MQTT Coupler with the IoT Hub can be seen in the IoT Hub overview under "IoT Hub usage". The active connections and the number of messages used are displayed there.



Additionally, you can view the received messages in the Azure Console. The following command starts the MQTT event monitoring:

```
az iot hub monitor-events -n <Hub-Name> -d <device-ID>
```

example:

```
az iot hub monitor-events -n HelmholzIOT -d PNMQTTCoupler
```

```
Bash
Requesting a Cloud Shell.Succeeded.
Connecting terminal...

Welcome to Azure Cloud Shell

Type "az" to use Azure CLI
Type "help" to learn about Cloud Shell

carsten_bokholt@Azure:~$ az iot hub monitor-events -n HelmholzIOT -d PNMQTTCoupler
The command requires the extension azure-iot. Do you want to install it now? The command will continue to run after the extension is installed. (Y/n): Y
Run 'az config set extension.use_dynamic_install=yes_without_prompt' to allow installing extensions without prompt.
Dependency update (uamqp 1.2) required for IoT extension version: 0.10.13.
Continue? (y/n) -> Y
Updating required dependency...
Update complete. Executing command...
Starting event monitor, filtering on device: PNMQTTCoupler, use ctrl-c to stop...
{
  "event": {
    "origin": "PNMQTTCoupler",
    "module": "",
    "interface": "",
    "component": "",
    "payload": "{\n  \"Out_DoubleWord_QD120\": \"0x011F1348\", \n  \"Milliseconds\": 18813768, \n  \"Cycle counter\": 18002811\n}"
  }
}
```

19 Technical data

Order no.	700-162-3MQ02
Article designation	PN/MQTT Coupler
PROFINET interface (X1)	
Connection	2x RJ45, integrated switch
Protocol	PROFINET IO Device as defined in IEC 61158-6-10
Transmission rate	100 Mbit/s full duplex
I/O image size	Up to 1024 Byte of input and output data
Number of configurable slots	100
Features	PROFINET Conformance Class B (<i>in preparation</i>), media redundancy (MRP-Client), automatic addressing, Topology detection (LLDP, DCP), diagnosis alarms
MQTT interface (X2)	
Connection	2x RJ45, integrated switch
Protocol	MQTT V3.1.1 & V5
Transmission rate	10/100 Mbit/s, full-/half duplex
Status indicator	9 LEDs function status, 8 LEDs Ethernet-status
Voltage supply	DC 24 V (18 - 28 V DC)
Current draw	max. 210mA
Power dissipation	max. 5 W
Dimensions (D x W x H)	35 x 58 x 72 mm (without power supply connector)
Weight	approx. 135 g
Certifications	PROFINET Conformance Class B (<i>in preparation</i>)
Noise immunity	DIN EN 61000-6-2 "EMC Immunity"
Interference emission	DIN EN 61000-6-4 "EMC Emission"
Vibration and shock resistance	DIN EN 60068-2-6:2008 "Vibration" DIN EN 60068-2-27:2010 "Shock"
Protection rating	IP 20
Relative humidity	95% non-condensing
Mounting position	any
Ambient temperature	0° C to 60° C
Transport and storage temperature	-20° C to 80° C